

EN



User manual

Digital Household-Thermometer with talking function Model E376 Item-no.: 5-1042

Thank you for choosing our digital SUNARTIS® household thermometer with talking function.

Before using this product, please read this instruction manual and specifically the safety instructions carefully. Please keep this instruction manual for later reference and pass it on to another user in case of transfer of ownership.

Due to its wide measuring range, this thermometer is useful for many fields of application:

- As a roast/meat thermometer
- As a BBQ thermometer
- As a thermometer for wine, tea and other cold and hot beverages
- As a thermometer for soups and sauces
- As a baking thermometer
- As a thermometer for controlling the optimal temperature of baby food/milk and for many applications more

Specification and technical data:

- Clear talk of reading in German or English language
- Foldable measuring probe to switch on/off the thermometer
- Very fast reaction- and measuring time (ca. 4 - 10 seconds)
- Large LC Display with red backlight
- Measuring accuracy: 0°C till 100°C ($\pm 1^\circ\text{C}$), -20°C till 1°C and 101°C till 200°C ($\pm 2^\circ\text{C}$), $< -20^\circ\text{C}$ and $> 200^\circ\text{C}$ ($\pm 5^\circ\text{C}$)
- Measuring range: -20°C till $+250^\circ\text{C}$
- Resolution: $0,1^\circ\text{C}/0,1^\circ\text{F}$
- Selectable reading: $^\circ\text{C}/^\circ\text{F}$
- Material casing: high quality ABS plastic
- Material probe: Stainless steel 18/8 (304)
- Batteries: 2 x 1,5V AAA Maxell LR03, included

Instruction manual:

Caution!

- **Clean the measuring probe before the first and after each use with a damp cloth and a little detergent if necessary. Do not immerse the whole product under water! The plastic housing contains batteries and electronic components, which are not waterproof.**
 - **Never use the thermometer in a closed oven or in microwave ovens.**
- 1) Clean the measuring probe before the first use.
 - 2) Raise the sensor to turn on the unit. The thermometer will report the voice message "Ready".
 - 3) The display indicates the current ambient temperature. To display the temperature in Fahrenheit, open the battery compartment and press the switch °C / °F
 - 4) To change the language, open the battery compartment and press the switch EN / GE.
 - 5) Insert the measuring probe at least 2 cm into the material being measured. The temperature indication is correct, when the value in the display remains constantly. It takes about 4-10 seconds.
 - 6) By pressing the button next to the display, the thermometer reports a voice message of the currently measured value.
 - 7) To measure the temperature during cooking or baking, open the oven, pull out the measuring object and measure the temperature as described above. Take the thermometer out **before** pushing back the food into the oven.
 - 8) Fold the sensor again to turn off the item. The selected unit will retain after power off.
 - 9) Clean the measuring probe after use.

Battery replacement:

- 1) Open the battery compartment on the back of the thermometer.
- 2) Replace two new 1,5V AAA (LR03) batteries. Observe the polarity.
- 3) Close the battery compartment.
- 4) After the battery replacement, the thermometer indicates the temperature in °C.

General notes on the battery:

The talking function requires a lot of energy.

If the batteries are not sufficiently charged, "LO" appears in the display. The thermometer can now only be used without talking function, until the batteries are replaced.

Safety instructions:

Caution!

- **Keep the product and the packaging film away from babies and children. There is danger of suffocation because of small parts and the packaging film.**
- **The measuring probe is pointed – CAUTION - risk of injury!**
- **Do not use the digital household thermometer for determining the body temperature. It is not approved as a medical device. The pointed top of the measuring probe may cause injury.**
- **Proceed carefully with the thermometer and do not store standing with the top up - risk of injury!**
- **Clean the measuring probe before the first and after each use with a damp cloth and a little detergent if necessary.**
- **The thermometer is not waterproof and not dishwasher safe. Do not immerse the whole product under water.**
- **Never use the thermometer in a closed oven or in microwave ovens! The electronics and the batteries in the handle are not suitable for these temperatures.**
- **Please also note the battery information in the section „Battery replacement“.**
- **This device is not intended to be used with reduced physical, sensory or mental capabilities or lack of experience and / or knowledge by persons (including children), unless they are supervised by a person responsible for their safety or after instructions by a person on how to use the device.**
- **Children should be supervised to ensure that they do not play with the appliance.**

General information:



Battery Ordinance:

Please note that the unit contains batteries. Batteries shall, by law, not be disposed of with regular household waste. Please dispose of the batteries in a municipal collection. You may also return the batteries to the manufacturer for disposal.

More information is available on the website of the Federal Ministry for the Environment, Nature Conservation and Nuclear Safety:

www.bmu.de

General information:



Battery Ordinance:

Please note that the unit contains batteries. Batteries shall, by law, not be disposed of with regular household waste. Please dispose of the batteries in a municipal collection. You may also return the batteries to the manufacturer for disposal.

More information is available on the website of the Federal Ministry for the Environment, Nature Conservation and Nuclear Safety:
www.bmu.de

Disposal:



The device is subject to the provisions of the Waste Electrical and Electronic Equipment Act (WEEE). The disposal of these electrical appliances in household waste is prohibited by the ElektroG (electric law). As a consumer, you are obliged to disposal via the local collection and return systems of the municipality.

For more information, visit the website of the Waste Electrical Equipment register www.stiftung-ear.de

Packaging:



The packaging materials can be recycled. Dispose of in an environmentally friendly manner.

Interseroh:



We participate in the DSD system. Please help us by listening to an appropriate disposal.

CE:



By the CE marking (Conformité Européenne), the manufacturer confirms that the product complies with the applicable European directives on product safety.

Customer service:

For questions, Mingle Instrument GmbH Europe is at your disposal. You can reach us by telephone during normal office hours, Monday to Friday from 8.00 to 17.00 clock, as well as at any time by e-mail.



Schmelzerstr. 30 D-47877 Willich
Tel.: 00800 / 128 128 12

www.mingle-europe.de - service@mingle-europe.de